


BEWM Series

High Wall Indoor Unit

Service Manual

220~240V/1/50Hz



CONTENTS

| | |
|---|-----------|
| 1 Main PCB Ports | 2 |
| 2 Indoor Unit Field Settings | 18 |
| 3 Display Panels | 23 |
| 4 Control | 26 |
| 5 Errors | 32 |
| 6 Troubleshooting | 35 |
| 7 Appendix..... | 59 |

1 Main PCB Ports

1.7 Wall-mounted Unit

Figure 1.8: Wall-mounted Unit main PCB ports (Model 22/28/36)




Table 1.8: Wall-mounted Unit main PCB ports (Model 22/28/36)

| Label in Figure 1.8 | Code | Content | Port voltage | Note |
|---------------------|------|---|--------------|------------|
| 1 | CN1 | AC power input | 220V AC | Standard |
| 2 | CN2 | ALARM/Pump drive port | 220V AC | Customized |
| 3 | CN18 | X1 X2 communication port | 18V DC | Customized |
| | | P Q E communication port | 2.5-2.7V DC | Standard |
| 4 | CN8 | Capability dial switch connection port | | Standard |
| 5 | CN13 | Vertical louver | 12V DC | Standard |
| 6 | CN19 | Red: Indoor heat exchanger outlet temperature sensor connection; White: Indoor ambient temperature sensor connection; Black: Indoor heat exchanger mid-point temperature sensor connection; | 5V DC | Standard |
| 7 | CN12 | Display panel connection | 5V DC | Standard |
| 8 | CN55 | Remote on/off switch connection | 12V DC | Standard |
| 9 | CN8 | PG FAN Back | 12V DC | Standard |
| 10 | CN5 | Water level switch connection | 5V DC | Standard |
| 11 | CN6 | EEV drive port | 12V DC | Standard |
| 12 | CN4 | PG Fan connection | 220V AC | Standard |

Notes:

Standard: The model has this function, the customers can connect corresponding device through this port, such as water pump and hotel key card etc.

Customized: This function needs to be customized before leaving the factory.

Reserved: This port can not be used.

Figure 1.9: Wall-mounted Unit main PCB ports (Model 45/56)




Table 1.9: Wall-mounted Unit main PCB ports (Model 45/56)

| Label in Figure 1.9 | Code | Content | Port voltage | Note |
|---------------------|------|---|--------------|------------|
| 1 | CN1 | AC power input | 220V AC | Standard |
| 2 | CN2 | ALARM/Pump drive port | 220V AC | Customized |
| 3 | CN8 | PG FAN Back | 12V DC | Standard |
| 4 | CN13 | Vertical louver | 12V DC | Standard |
| 5 | CN55 | Remote on/off switch connection | 12V DC | Standard |
| 6 | CN19 | Red: Indoor heat exchanger outlet temperature sensor connection; White: Indoor ambient temperature sensor connection; Black: Indoor heat exchanger mid-point temperature sensor connection; | 5V DC | Standard |
| 7 | CN12 | Display panel connection | 5V DC | Standard |
| 8 | CN6 | EEV drive port | 12V DC | Standard |
| 9 | CN18 | X1 X2 communication port | 18V DC | Customized |
| | | P Q E communication port | 2.5-2.7V DC | Standard |
| 10 | CN5 | Water level switch connection | 5V DC | Standard |
| 11 | CN4 | PG Fan connection | 220V AC | Standard |

Notes:

Standard: The model has this function, the customers can connect corresponding device through this port, such as water pump and hotel key card etc.

Customized: This function needs to be customized before leaving the factory.

Reserved: This port can not be used.

Figure 1.10: Wall-mounted Unit main PCB ports (Model 71/80/90)




Table 1.10: Wall-mounted Unit main PCB ports (Model 71/80/90)

| Label in Figure 1.10 | Code | Content | Port voltage | Note |
|----------------------|------|---|--------------|------------|
| 1 | CN1 | AC power input | 220V AC | Standard |
| 2 | CN2 | ALARM/Pump drive port | 220V AC | Customized |
| 3 | CN3 | Check key connection | 5V DC | Standard |
| 4 | CN12 | Display panel connection | 5V DC | Standard |
| 5 | CN18 | X1 X2 communication port | 18V DC | Customized |
| | | P Q E communication port | 2.5-2.7V DC | Standard |
| 6 | CN13 | Vertical louver | 12V DC | Standard |
| 7 | CN55 | Remote on/off switch connection | 12V DC | Standard |
| 8 | CN6 | EEV drive port | 12V DC | Standard |
| 9 | CN5 | Water level switch connection | 5V DC | Standard |
| 10 | CN19 | Red: Indoor heat exchanger outlet temperature sensor connection; | 5V DC | Standard |
| | | White: Indoor ambient temperature sensor connection; | | |
| | | Black: Indoor heat exchanger mid-point temperature sensor connection; | | |
| | | | | |
| 11 | CN8 | PG FAN Back | 12V DC | Standard |
| 12 | CN4 | PG Fan connection | 220V AC | Standard |

Notes:

Standard: The model has this function, the customers can connect corresponding device through this port, such as water pump and hotel key card etc.






Customized: This function needs to be customized before leaving the factory.

Reserved: This port can not be used.

2 Indoor Unit Field Settings

2.1.3 Wall Mounted

Table 2.5: Wall Mounted main PCB settings

| Switch | Setting | Switch positions ¹ | Description |
|--------------|------------------------------|---|---|
| J1(optional) | Auto restart ² |  | Auto restart function enabled |
| | |  | Auto restart function disabled |
| J2(optional) | Pump and Alarm signal output |  | CN2 port: Pump signal output |
| | |  | CN2 port: Alarm signal output |
| ENC1 | Indoor unit capacity |  | 0: 1/1.2kW; 1: 1.5/1.7/1.8kW; 2: 2.2kW; 3: 2.5/2.8kW; 4: 3.2/3.6kW 5: 4.0kW; 6: 4.5kW; 7: 5.0/5.6kW; 8: 6.3/7.1kW; 9: 8.0kW; A:8.5/9.0; B:10.0/10.4/10.6kW; C:11.2kW; D:12.0/12.5/12.8kW; E: 14kW |

Notes:

1. The black rectangles denote the switch positions.
2. Refer to [2.2.3 "Auto restart setting"](#).

2.2 Modes Set on Main PCBs

2.2.1 Auto restart setting








The auto restart function can be used to ensure that, in the event of a power outage, the indoor units automatically restart once the power returns. When the power returns following a power outage, units with auto restart enabled restart with the same operating mode, fan speed and remote control lock status settings as before the power outage. The restart of indoor units is staggered, with the start-up of some units delayed to prevent all units starting-up simultaneously. If, during this timed delay, the remote or wired controller is used to send a command to a unit, that unit starts-up immediately with those new settings. Indoor units with auto restart disabled go into standby once the power returns following a power outage.

3 Display Panels

3.1 Appearance of Display Panel

The appearance of the digital display panel used is shown in Figures 3.1.

Figure 3.1: Digital display panel¹



| | |
|---|--|
| <p>Display panel for four-way cassette (New 360 degree panel, standard panel)</p> | <p>Display panel for four-way cassette (Optional)</p> |
|  |  |
| <p>Display panel for compact four-way cassette</p> | <p>Display panel for one-way cassette</p> |
|  |  |
| <p>Display panel for ceiling and floor</p> | <p>Display panel for two-way cassette, medium static pressure duct and high static pressure duct</p> |
|  |  |
| <p>Display panel for Wall Mounted²</p> | |
|  | |

Notes:

1. The pictures are just for reference, the exact appearance of digital panel maybe slightly different.
2. For Wall Mounted, the digital display needs to be customized.

3.2 Output under Normal Operating Conditions

Table 3.1: Display panel output under normal operating conditions

| Unit state | | Display output | |
|----------------------|--|--|---|
| | | Lights/Icons | Digital display |
| Standby | | Operation indicator flashes slowly |  |
| Shutting-down | | All indicators off? |  |
| Operating | Normal operation | Operation indicator on | Cooling and heating modes: set temperature Fan only mode: indoor ambient temperature |
| | Cold draft prevention or outdoor unit defrosting operation | Operation and Anti-cold / defrosting indicators on | Set temperature |
| A timer has been set | | Timer indicator on | n/a |

Notes:

1. The display panel should be installed in the ceiling, nothing can be exposed but the panel face.

3.3 Digital Display Parameter Output

On pressing the manual button^{1,2} on a digital display panel the parameters given in Table 3.1 are displayed (unless the unit is in an error state, in which case the digital display displays the error code). On the first press, parameter no. 1 is displayed, on the second press, parameter no. 2 is displayed, and so on. If the button is not pressed for 10 seconds, the display returns to its normal display, as described in Table 3.1.

Notes:

1. The manual buttons refer to 3.1 "Appearance of Display Panel".
2. For the four-way cassette's new 360 degree panel, a needle is necessary to active manual button.

3.3.1 Spot check table

Table 3.1: Digital display output when button on a digital display panel is pressed

| Parameter no. | Parameters | Remarks |
|---------------|--|--|
| 0 | Normal display | |
| 1 | Communication address ¹ | 0 - 63 |
| 2 | Capacity as set on ENC1 switch on indoor unit main PCB | Unit: HP |
| 3 | Network address ¹ | 0 - 63 |
| 4 | Set temperature Ts | |
| 5 | T1 indoor temperature | Minimum value -9°C |
| 6 | T2 indoor heat exchanger mid-point temperature | Minimum value -9°C |
| 7 | T2A Indoor heat exchanger inlet temperature | Minimum value -9°C |
| 8 | T2B Indoor heat exchanger outlet temperature | Minimum value -9°C |
| 9 | Compressor discharge temperature | |
| 10 | Target superheat (reserved) | |
| 11 | EXV steps (actual steps / 8) | |
| 12 | Version number of indoor unit's main program software | |
| 13 | Swing small board software version number | Only available for Q4 360 degree panel and A5 duct intelligent panel. Apart from above conditions, it shows "0". |
| 14 | Error code 1 (last time) | |
| 15 | Error code 2 (last but one) | |
| 16 | Error code 3 (last but two) | |
| 17 | Number of times the IDU address was set using ODU Auto Addressing Switch (Record 99 times at most) | |
| 18 | Number of times the IDU address was set using remote controller (99 times at most) | |
| 19 | Number of times the IDU address was set using wired controller (99 times at most) | |
| 20 | -- | |

Notes:

1. For indoor units, the communication address and network address are the same and are routinely referred to simply as the unit's "address".

4 Control

4.1 EXV Control

When the IDU is powered on again or the ODU is stopped, the system automatically enters initialization mode. After initialization is completed, the system enters the normal start mode. The IDU EXV uses superheat degree control in cooling mode and uses supercool degree control in heating mode. If the IDU receives a protection control or special control command, this command is executed in priority.

- **Superheat Degree Control in Cooling Mode**

During cooling (dry), the IDU calculates the difference of the indoor evaporator outlet temperature (T_{2B}) received and the average value ($\overline{T_{2B}}$) of the evaporator outlet temperature detected by the IDU and sent by the ODU based on the following formula and uses the difference as the current superheat degree (SH). By comparison of the current superheat degree (SH) with the set superheat degree (SHS), the opening adjustment trend of the EXV can be decided.

$$T_{2B} - \overline{T_{2B}} = SH$$

- ◆ When $SH > SHS$, the EXV opening increases
- ◆ When $SH = SHS$, the EXV opening unchanged
- ◆ When $SH < SHS$, the EXV opening decreases

- **Supercool Degree Control in Heating Mode**

During heating, the IDU calculates the difference of the indoor evaporator middle temperature (T_2) received and the average value ($\overline{T_2}$) of the evaporator middle temperature detected by the IDU and sent by the ODU based on the following formula, and uses the difference as the current supercool degree (SC). By comparing the current supercool degree (SC) with the set supercool degree (SCS), the opening adjustment trend of the EXV can be determined.

$$T_2 - \overline{T_2} = SC$$

- ◆ When $SC > SCS$, the EXV opening increases
- ◆ When $SC = SCS$, the EXV opening unchanged
- ◆ When $SC < SCS$, the EXV opening decreases

- **EXV Operating in Different Situations**

The EXV decides its operating opening based on the IDU operating mode, IDU working mode, and ODU working mode. For details, see the following table:

| IDU Status | Cooling Mode | | Heating Mode | |
|------------|-------------------|-------------|-------------------|-------------|
| | ODU Operating | ODU Stopped | ODU Operating | ODU Stopped |
| Operating | Superheat control | | Supercool control | |
| Standby | | | | |
| Off | 0 PLS | 300 PLS | 72 PLS | 300 PLS |
| Fault | | | | |

Note:

PLS indicates the unit of pulses regarding the EXV opening.


4.2 Start and Stop Control

After receiving the operating requirements from the remote controller, wired controller, or centralized controller, the IDU determines the operating status based on the difference of the detected return air temperature (T_1) and the user set temperature (T_s). Due to imbalanced distribution of indoor heat, solar radiation, the rising of hot air, and other factors, the


return air temperature detected by the return air temperature sensor (T_1) of the IDU differs from the temperature in the area where users are active. This will cause the air temperature of the activity area to differ from the user set temperature when the IDU reaches the set temperature and enters standby mode. There are two solutions to this problem:

1. Enable Follow Me. The IDU will use the temperature detected by the indoor temperature sensor of the controller as the return air temperature to determine whether the machine operates or remains in standby mode.
2. Enable temperature compensation to add the temperature compensation value ΔTC to $(T_1 - T_s)$. This revises the difference of the return air temperature and that of the activity area caused by the preceding factors.

● Cooling (Dry)



● Heating



Note:

For the temperature compensation value ΔTC in cooling or heating mode, see the user manual of different machine types. For details, consult the local technical support engineers.

4.3 Fan Control

The IDU can work in seven-speeds (strong, super-high, high, middle, low, breeze, and sleep) or three-speed mode. For details about specific modes, see the technical manual of corresponding unit type.

● **Fan Control in Different Situations**


| Operating in Set Speed | IDU Status | Cooling Mode | Dry Mode | Heating Mode | Fan Mode | Speed Switch |
|------------------------|------------|--------------|----------------|---|-----------|--|
| | Operating | Set speed | Low | Set speed | Set speed | User set |
| | Standby | Set speed | Low | Specified mode | / | |
| | Off | Stop fan | Stop fan | Stop fan | Stop fan | |
| | Fault | Stop fan | Stop fan | Stop fan | Stop fan | |
| Automatic Fan Speed | IDU Status | Cooling Mode | Heating Mode | Auto | Fan Mode | Speed Switch |
| | Operating | Automatic | Automatic | Automatic | Low | Switch fan speed based on the difference of the set temperature and return air temperature |
| | Standby | Automatic | Specified mode | Automatic cooling, automatic fan speed, automatic heating, and specified mode operating | / | |
| | Off | Stop fan | Stop fan | Stop fan | Stop fan | |
| | Fault | Stop fan | Stop fan | Stop fan | Stop fan | |

Note:

When the IDU fan changes from specified mode to heating and standby mode, it will stop for a period of time. The length of this period can be set. After this period, the fan will operate in low mode for one minute.


● **Air Guide Louver Swing Control**

- 1) Swing angle is controlled through the stepper motor. It has five levels. After the swing angle is set, the IDU automatically records the swing angle and jumps to this initial angle by default each time the machine is started. The swing angle can be set to different values based on the IDU type.
- 2) After a start signal is received, if the air guide louver has been zeroed, it will open immediately. If the air guide louver is being zeroed, it will open again after zeroing. The fan start is delayed.
- 3) After the stop signal is received, the air guide louver is closed to the minimum angle P₀, and this position is kept 60 seconds after the fan is stopped, the air guide louver is closed. If the IDU encounters anti-cold air during heating, the fan turns off immediately. The air guide louver will remain at its current angle.



● **Anti-cold Air Control**

This function may only be used in heating mode. Fan speed is changed according to the middle temperature (T_2) of the evaporator. While in anti-cold air mode, if the indoor fan is off, the preheat/defrost indicator is on; once the indoor fan is off, the preheat/defrost indicator turns off. When the IDU is in heating mode, the anti-cold air control is valid during the oil return or defrosting period. If the IDU is turned off, the fan is turned off as well.



Note:


When the fan is turned off, the middle temperature (T_2) of the evaporator can be set through the DIP or controller.

4.4 Auto Mode

Upon receiving an auto mode signal, the IDU determines a mode based on logic. If the determined mode is consistent with the ODU mode, the IDU operates in the ODU mode. If the determined mode is different from the ODU mode, the IDU controls based on the mode conflict control logic. During the initial power-on, the temperature is set as follows in auto

mode: temperature in heating $T_{sh} = 21^\circ\text{C}$, temperature in cooling $T_{sc} = 24^\circ\text{C}$. The cooling temperature is set prior to the heating temperature. $D2 = \text{Cooling temperature} - \text{Heating temperature} \geq 0^\circ\text{C}$. $D1$ and $D3$ indicate the on and off return difference in cooling mode and the on and off return difference in heating mode, respectively.

- **Switching Modes**



● **Set Temperature Display**

- 1) When switching between cooling, heating or auto modes, if temperature Ts is not reset, the temperature after switching is the same as the temperature before switching.
- 2) In auto mode, switching between cooling and heating mode takes some time. The time can be set through the controller.

4.5 Mode Conflict

If the IDU start mode differs from the ODU start mode, a mode conflict failure is reported by the IDU. The following table lists failures reported in different IDU and ODU statuses.

| ODU Type | | ODU Status | | |
|------------------|------------|------------|---------|---------|
| IDU Type | IDU Status | Off | Cooling | Heating |
| Conventional IDU | Cooling | No | No | Yes |
| | Dry | No | No | Yes |
| | Heating | No | Yes | No |
| | Fan | No | No | Yes |
| V6 DC FAPU | Cooling | No | No | Yes |
| | Heating | No | Yes | No |
| | Fan | No | No | No |

Note:

FACU stands for Fresh Air Processing Unit.

4.6 Controlling the Condensate Water Pump and Water Level Switch

- 1) When the IDU is powered on the first time, the water pump is forced to operate for five minutes.
- 2) When the IDU and ODU are in cooling mode, the water pump starts immediately and operates continuously. After this mode is stopped (stop and mode switch), the water pump turns off five minutes later.
- 3) If the water level rises, causing the water level switch to be disconnected, the condensate water pump immediately starts and operates. Five minutes later, if the water level drops to lower than the alarm level, the system restores operation based on the originally set mode. Otherwise, the IDU and water pump stop operating, and a water level alarm is reported. When the water level switch is connected again, the protection is released, and the system restores operation based on the mode that was originally set.

Note:

This function is reserved for the unit models without drainage pumps and water level switches and it is disabled by default.

4.7 Anti-freeze Control

During cooling or drying, if the detected indoor evaporator outlet temperature (T_{2B}) or indoor evaporator middle temperature (T_2) drops too low, the machine enters anti-freeze control based on the following conditions. When anti-freeze protection is triggered, the IDU will not display an error code, the EXV is closed, the compressor output is dropped, the drainage pump operates continuously, and the fan operates based on the set speed. When the indoor evaporator outlet temperature (T_{2B}) or indoor evaporator middle temperature (T_2) rises to a specific threshold, anti-freeze protection shuts off.

4.8 Display Function

- 1) In standby mode, the operating indicator continues flashing slowly, and "--" appears on both digital displays.
- 2) While the unit is stopped, the operating indicator is off, and "--" appears on both digital displays.
- 3) While the unit is operating, the operating indicator is on, and two digital displays are on. In cooling or heating mode, the digital display shows the set temperature. In fan mode, the digital display shows the indoor temperature.
- 4) When anti-cold air is on, if the indoor fan is off, the preheat/defrost indicator is on; when the indoor fan is on, the preheat/defrost indicator is off.
- 5) When defrost is on, the preheat/defrost indicator is on. After defrosting ends, the preheat/defrost status is

determined based on the anti-cold air protection. If the IDU is equipped with a VR heat recovery ODU, the defrost indicator is not displayed when the defrost signal is changed to ON.

- 6) The timer indicator is not on when the light button is set to off.
- 7) When the IDU receives a non-inquiry command from the remote controller or wired controller, the operating indicator and digital display are on.
- 8) When the IDU receives the address inquiry command from the remote controller or wired controller, the indicator is off, and the digital display is on and shows the address. The indicator will turn on after 10s and the digital display shows the operating status.
- 9) When the IDU receives any command from the centralized controller, the digital display or indicator on the display board will be on.
- 10) In the fault status, the digital display is on, and the error code is displayed (see the error code list for details). After the fault is cleared, the IDU operates and can be controlled normally.




5 Errors

5.1 Error Code Table

Table 5.1: Error code table

| Error code | Content |
|----------------------|--|
| E0 | Mode conflict |
| E1 | Communication error between indoor and outdoor units |
| E2 | Indoor ambient temperature sensor error |
| E3 | Indoor heat exchanger mid-point temperature sensor error |
| E4 | Indoor heat exchanger outlet temperature sensor error |
| E6 | Fan error |
| E7 | EEPROM mismatch |
| E9 | Communication error with wired controller |
| Eb | Electronic expansion valve error |
| Ed | Outdoor unit error |
| EE | Water level error |
| FE | Indoor unit has not been assigned an address |
| H4 | Communication error between main board and display board |
| H5 | EEPROM of display board damaged |
| A1 | Refrigerant leakage fault |
| A0 | The emergency stop |
| F7+ repeated address | Repeated indoor units address |
| U4 | MS box self-check failure |
| F8 | MS box Error |
| FA | Capacity(HP) has not been set |

Table 5.2: Error code table of Wall Mounted

| Phenomenon | Flash Times | Error code | Content |
|---|-------------|----------------------|--|
|  | 1 | E0 | Mode conflict |
| | 2 | E1 | Communication error between indoor and outdoor units |
| | 3 | E2 | Indoor ambient temperature sensor error |
| | 4 | E3 | Indoor heat exchanger mid-point temperature sensor error |
| | 5 | E4 | Indoor heat exchanger outlet temperature sensor error |
| | 6 | E6 | Fan error |
| | 7 | E7 | EEPROM mismatch |
| | 8 | / | / |
|  | 1 | Eb | Electronic expansion valve error |
| | 2 | Ed | Outdoor unit error |
| | 3 | EE | Water level error |
| | 4 | A0 | The emergency stop |
| | 5 | A1 | Refrigerant leakage fault |
| | 6 | FE | Indoor unit has not been assigned an address |
| | 7 | FA | Capacity(HP) has not been set |
| | 8 | H4 | Communication error between indoor unit and panel |
|  | 1 | U4 | MS box self-check failure |
| | 2 | F8 | MS box Error |
| | 3 | F7+ repeated address | Repeated indoor units address |

5.2 Impact on Other Units

Table 5.3 shows the impact of an error on one indoor unit on the outdoor units and on the other indoor units in the system. The actual state of the outdoor units and the other indoor units is determined not only by the impacts shown in Table 4.3, but also by any other errors that may have separately arisen on the outdoor units or other indoor units.

Table 4.3: Impact of indoor unit error on outdoor units and on other indoor units

| Indoor unit error | Impact on outdoor units | Impact on other indoor units |
|-----------------------------------|-----------------------------|------------------------------|
| E0 | Minimal impact ¹ | No impact |
| E1 | H7 error ² | Ed error ³ |
| E2 | Minimal impact ⁴ | No impact |
| E3 | Minimal impact ⁴ | No impact |
| E4 | Minimal impact ⁴ | No impact |
| E6 | Minimal impact ⁴ | No impact |
| E7 | Minimal impact ⁴ | No impact |
| E9 | No impact | No impact |
| Eb | Minimal impact ⁴ | No impact |
| Ed | n/a ⁵ | n/a ⁵ |
| EE | Minimal impact ⁴ | No impact |
| FE | H7 error ² | Ed error ³ |
| H5 | Minimal impact ⁴ | No impact |
| H4 | Minimal impact ⁴ | No impact |
| A1 ⁶ | No impact | Ed error ³ |
| A0 ⁶ | No impact | Ed error ³ |
| F7+ repeated address ⁵ | No impact | No impact |
| U4 ⁶ | No impact | No impact |
| F8 ⁶ | No impact | Ed error ³ |
| FA | No impact | No impact |
| H4 | Minimal impact ⁴ | No impact |

Notes:

1. The outdoor units continue to operate and ignore the load requirement from the indoor unit that has gone into mode conflict with the outdoor units.
2. Outdoor unit error code H7 indicates that the number of indoor units detected by the master outdoor unit is not the same as the number set on the master outdoor unit's main PCB.
3. Error Ed may not be displayed on the other indoor units. Indoor unit error codes have the following order of priority: A1-A0-FE-F7-E0-E1-E2-E3-E4-E6-E7-Eb-Ed-EE-H4-U4-F8. So if, for example, one unit has an E2 error, it continues to display E2 even if an E1 or FE error occurs on another indoor unit (giving rise to an outdoor unit H7 error) since error Ed is lower in the order of priority than error E2.
4. The outdoor units continue to operate but detect no load requirement from the indoor unit that has experienced an E2, E3, E4, E6, E7, Eb or EE error, and adjust their output accordingly, in the same way as they do when a user puts an indoor unit into standby.
5. An indoor unit Ed error is caused by (and not the cause of) an outdoor unit error. The outdoor units will be displaying their own error code.
6. Only applicable for V6R system.

6 Troubleshooting

6.1 Warning

Warning



- All electrical work must be carried out by competent and suitably qualified, certified and accredited professionals and in accordance with all applicable legislation (all national, local and other laws, standards, codes, rules, regulations and other legislation that apply in a given situation).
- Power-off the unit before connecting or disconnecting any connections or wiring, otherwise electric shock (which can cause physical injury or death) may occur or damage to components may occur.

6.2 E0 Troubleshooting

6.2.1 Display output



6.2.2 Description

- Mode conflict.

6.2.3 Impact on other units

- Refer to [5.2 “Impact on Other Units”](#).

6.2.4 Possible causes

- The indoor unit's operating mode conflicts with that of the outdoor units.

6.2.5 Explanation

There are five priority mode options, which are set on the outdoor units. If an indoor unit's operating mode conflicts with that of the outdoor units, the indoor unit displays the mode conflict error. The five priority modes are:

1. **Heating priority mode (default):**

- a) **During cooling operation:** If an indoor unit requests heating, the outdoor units stop and then restart in heating mode after 5 minutes. Indoor units requesting heating then start in heating mode and indoor units requesting cooling display the mode conflict error.
- b) **During heating operation:** If an indoor unit requests cooling, the outdoor units ignore the request and continue to run in heating mode. The indoor unit requesting cooling displays the mode conflict error. If all the indoor units requesting heating are later turned off and one or more indoor units are still requesting cooling, the outdoor units restart in cooling mode after 5 minutes and any indoor units requesting cooling then start in cooling mode.

2. **Cooling priority mode:**

- a) **During heating operation:** If an indoor unit requests cooling, the outdoor units stop and then restart in cooling mode after 5 minutes. Indoor units requesting cooling then start in cooling mode and indoor units requesting heating display the mode conflict error.
- b) **During cooling operation:** If an indoor unit requests heating, the outdoor units ignore the request and continue to run in cooling mode. The indoor unit requesting heating displays the mode conflict error. If all the indoor units requesting cooling are later turned off and one or more indoor units are still requesting heating, the outdoor units restart in heating mode after 5 minutes and any indoor units requesting heating then start in heating mode.

3. **VIP priority mode or voting priority mode:** 63 is the VIP address. If the VIP indoor unit is operating, the outdoor units operate in the mode of the VIP indoor unit. Indoor units that are in a mode different to that of the VIP unit display the mode conflict error. If there is no unit with address 63 or the unit at address 63 is in standby, the outdoor units operate in voting priority mode. In voting priority mode, the outdoor units operate in whichever of heating and cooling modes is being requested by the larger number of indoor units.

4. **Heating only mode:** The outdoor units only operate in heating mode. Indoor units requesting heating operate in heating mode. Indoor units requesting cooling or in fan only mode display the mode conflict error.

5. **Cooling only mode:** The outdoor units only operate in cooling mode. Indoor units requesting cooling operate in cooling mode; indoor units in fan only mode operate in fan only mode. Indoor units requesting heating display the mode conflict error.

6.3 E1 Troubleshooting

6.3.1 Display output



6.3.2 Description

- Communication error between indoor and outdoor units.


6.3.3 Impact on other units

- Refer to [5.2 "Impact on Other Units"](#).

6.3.4 Possible causes

- Communication wires between indoor and outdoor units not connected properly.
- Interference from high voltage wires or other sources of electromagnetic radiation.
- Communication wire too long.
- Damaged main PCB.

6.3.5 Procedure



Notes:

1. Measure the resistance among P, Q and E. The normal resistance between P and Q is 120Ω, between P and E is infinite, between Q and E is infinite.
2. The P Q E communication wires should be connected one unit after another in a daisy chain from the master outdoor unit to the final indoor unit. After the final indoor unit, the communication wiring should NOT be continued back to the outdoor units – that is, do not attempt to form a closed loop.
3. The refrigerant piping, power wiring and communication wiring are typically run in parallel. However the communication wiring should not be bound together with the refrigerant piping or power wiring. To prevent signal interference, the power wiring and communication wiring should not be run in the same conduit. If the power supply is less than 10A, a separation of at least 300mm between power wiring and communication wiring conduits should be maintained; if the power supply is in the range 10A to 50A then a separation of at least 500mm should be maintained.

6.4 E2, E3, E4 Troubleshooting

6.4.1 Display output



6.4.2 Description

- E2 indicates an indoor ambient temperature sensor error.
- E3 indicates an indoor heat exchanger mid-point temperature sensor error.
- E4 indicates an indoor heat exchanger outlet temperature sensor error.


6.4.3 Impact on other units

- Refer to 5.2 “Impact on Other Units”.

6.4.4 Possible causes

- Temperature sensor not connected properly or has malfunctioned.
- Damaged main PCB.

6.4.5 Procedure



Notes:

1. The indoor ambient temperature sensor connection port, indoor heat exchanger mid-point temperature sensor connection port and indoor heat exchanger outlet temperature sensor connection port on each type of indoor unit main PCB are labeled in Figures 1.1 to 1.19 in 1, “Main PCB Ports”.
2. Measure sensor resistance. If the resistance is too low, the sensor has short-circuited. If the resistance is not consistent with the sensor’s resistance characteristics table, the sensor has failed. Refer to Table 6.1 in 6.1 “Temperature Sensor Resistance Characteristics”.

6.5 E6 Troubleshooting Display output

6.5.1 Display output



6.5.2 Description

- Fan error.
- Either the main PCB cannot detect the fan, or the difference between the actual fan speed and the target fan speed exceeds the limit.


6.5.3 Impact on other units

- Refer to [5.2 "Impact on Other Units"](#).

6.5.4 Possible causes

- Fan stuck or blocked.
- Fan motor not connected properly or has malfunctioned.
- Power supply abnormal.
- Damaged main PCB.

6.5.5 Procedure



Notes:

1. The fan connection on Wall Mounted main PCB is labeled in Figures 1.6 to 1.8 in [1, "Main PCB Ports"](#).
2. Measure the voltage between the red and black wires and between the white and black wires at the fan connection on the indoor unit main PCB. The normal voltage between the red and black wires is 310V (DC); the normal voltage between the white and black wires is 15V (DC). The fan connection on each type of indoor unit main PCB is labeled in Figures 1.6 to 1.8 in [1, "Main PCB Ports"](#). Refer also to Figure 5.1.
3. Remove the fan motor and install a new one. Power-on the unit, set it to run with fan speed set to low, and see if the unit runs normally or not.

Figure 5.1: Fan connection wiring on indoor unit main PCBs



6.6 E7 Troubleshooting

6.6.1 Display output



6.6.2 Description

- EEPROM mismatch.


6.6.3 Impact on other units

- Refer to [5.2 "Impact on Other Units"](#).

6.6.4 Possible causes

- Damaged main PCB.

6.6.5 Procedure



6.7 E9 Troubleshooting

6.7.1 Display output



6.7.2 Description

- Communication error with wired controller.


6.7.3 Impact on other units

- Refer to 5.2 “Impact on Other Units”.

6.7.4 Possible causes

- Abnormal power supply to the wired controller
- Wired controller is damaged
- The communication wire is disconnected, short circuit or loose
- Communication wire is too long (maximum length can be 200m only)
- Main PCB of IDU is damaged

6.7.5 Procedure



6.8 Eb Troubleshooting

6.8.1 Display output



6.8.2 Description

- Electronic expansion valve error.


6.8.3 Impact on other units

- Refer to 5.2 “Impact on Other Units”.

6.8.4 Possible causes

- Electronic expansion valve coil not connected properly or has malfunctioned.
- Damaged main PCB.


6.8.5 Procedure



Notes:

1. The electronic expansion valve connection port on each type of indoor unit main PCB is labeled in Figures 1.1 to 1.19 in 1, “Main PCB Ports”.
2. The normal resistances between EXV coil wiring terminals RED and white / yellow / orange / blue are 40-50Ω. If any of the resistances is 0 or infinity, the EXV coil has malfunctioned.

Figure 5.2: EXV coil wiring terminals



6.9 Ed Troubleshooting

6.9.1 Display output



6.9.2 Description

- Outdoor unit error.


6.9.3 Impact on other units

- Refer to [5.2 "Impact on Other Units"](#).

6.9.4 Possible causes

- Outdoor unit error.

6.9.5 Procedure



6.10 EE Troubleshooting

6.10.1 Display output



6.10.2 Description

- Water level error.


6.10.3 Impact on other units

- Refer to 5.2 “Impact on Other Units”.

6.10.4 Possible causes

- Water level float stuck.
- Water level switch not connected properly.
- Damaged main PCB.
- Drain pump has malfunctioned.

6.10.5 Procedure



Notes:

- The water level switch connection port on each type of indoor unit main PCB is labeled in Figures 1.1 to 1.19 in 1, “Main PCB Ports”.
- Measure the voltage between the two pins of the drain pump connection on the indoor unit main PCB. The normal voltage range is 220 to 240 V (AC). The drain pump connection port on each type of indoor unit main PCB is labeled in Figures 1.1 to 1.19 in 1, “Main PCB Ports”.
- Measure the resistance between the two power supply terminals on the drain pump motor. If the resistance is either zero or infinite, the motor has malfunctioned.

6.11 FE Troubleshooting

6.11.1 Display output



6.11.2 Description

- Indoor unit has not been assigned an address.


6.11.3 Impact on other units

- Refer to [5.2 "Impact on Other Units"](#).

6.11.4 Possible causes

- Indoor unit has not been assigned an address.

6.11.5 Procedure



Notes:

- Indoor unit addresses can be manually assigned using indoor unit remote/wired controllers. Alternatively, indoor unit addresses can be automatically assigned by the master outdoor unit. Refer to the outdoor unit technical documentation. Note: Each unit in a system should be assigned a unique address - unit addresses should not be repeated within one system.

6.12 H4 Troubleshooting

6.12.1 Display output



6.12.2 Description

- Communication error between IDU main board and display board.


6.12.3 Impact on other units

- Refer to [3.2 "Impact on Other Units"](#).

6.12.4 Possible causes

- Communication wire between IDU main board and display board not connected properly.
- Panel is not compatible with the indoor unit.

6.12.5 Procedure



Notes:

1. The display board connection is port CN30 on the IDU main PCB (labeled 16 in Figure 1 in part 1 "Main PCB Ports").
2. Panel T-MBQ4-02E(S) is compatible with 16kW four-way cassette IDU.

6.13 H5 Troubleshooting

6.13.1 Display output



6.13.2 Description

- EEPROM of display board damaged.


6.13.3 Impact on other units

- Refer to [4.2 "Impact on Other Units"](#).

6.13.4 Possible causes

- EEPROM of display board damaged.

6.13.5 Procedure



Notes:

1. The display board connection is port CN30 on the IDU main PCB (labeled 16 in Figure 1-1.1 in 1 "Main PCB Ports").

6.14 Louver Swing Failure Troubleshooting

6.14.1 Display output

- No special display output or error code.


6.14.2 Description

- Louvers fail to respond to instruction from wired or remote controller.

6.14.3 Possible causes

- Louver swing motor not connected properly or has malfunctioned.
- Damaged main PCB.


6.14.4 Procedure



Notes:

1. The louver swing motor connection on each type of indoor unit main PCB is labeled in Figures 1.1 to 1.19 in 1, "Main PCB Ports".
2. Measure the resistance between the red wire and each of the other four wires (orange, yellow, pink and blue) at the louver swing motor connection on the main PCB. The resistances between the red wire and each of the other four wires should all be the same, should not be zero and should not be infinite. If the resistances are not the same, or if any of the resistances are zero or infinite, the louver swing motor has malfunctioned. The louver swing motor connection on each type of indoor unit main PCB is labeled in Figures 1.1 to 1.19 in 1, "Main PCB Ports". Refer also to Figure 5.2.

Figure 5.2: Louver swing motor connection wiring on indoor unit main PCBs



6.15 A1 Troubleshooting

6.15.1 Display output



6.15.2 Description

- Refrigerant leakage fault.


6.15.3 Impact on other units

- Refer to [5.2 “Impact on Other Units”](#).

6.15.4 Possible causes

- MS box actually detects that the quantity of connected refrigerant leakage sensors is not same as the quantity of sensors set by ENC1
- The refrigerant leakage sensor is open circuit, that is refrigerant leakage occurs
- MS box PCB malfunction

6.15.5 Procedure



6.16 A0 Troubleshooting

6.16.1 Display output



6.16.2 Description

- The emergency stop.


6.16.3 Impact on other units

- Refer to [5.2 "Impact on Other Units"](#).

6.16.4 Possible causes

- MS box actually detects that the quantity of connected refrigerant leakage sensors is not same as the quantity of sensors set by ENC1
- The refrigerant leakage sensor is open circuit, that is refrigerant leakage occurs
- MS box PCB malfunction

6.16.5 Procedure



6.17 F7+repeated address (Alternating display with 1s as cycle) Troubleshooting

6.17.1 Display output



6.17.2 Description

- Repeated indoor units address.


6.17.3 Impact on other units

- Refer to [5.2 "Impact on Other Units"](#).

6.17.4 Possible causes

- Multiple virtual addresses will appear in high pressure duct 20-56kw. And it didn't restart after setting the unit capacity. The refrigerant leakage sensor is open circuit, that is refrigerant leakage occurs
- There are other indoor units that repeat the address.

6.17.5 Procedure



Notes:

1. The repeated address displayed on the display board cannot be used. The address range is 0-63#

6.18 U4 Troubleshooting

6.18.1 Display output



6.18.2 Description

- MS box self-check failure.


6.18.3 Impact on other units

- Refer to [5.2 "Impact on Other Units"](#).

6.18.4 Possible causes

- During the commissioning of the outdoor unit, the Outdoor find the indoor unit PQE connection and real refrigerant pipe connection is mismatch under the MS.

6.18.5 Procedure



6.19 F8 Troubleshooting

6.19.1 Display output



6.19.2 Description

- MS box Error.


6.19.3 Impact on other units

- Refer to [5.2 "Impact on Other Units"](#).

6.19.4 Possible causes

- The connected MS box has error or protection.

6.19.5 Procedure



6.20 FA Troubleshooting

6.20.1 Display output



6.20.2 Description

- Capacity(HP) has not been set.


6.20.3 Impact on other units

- Refer to [5.2 "Impact on Other Units"](#).

6.20.4 Possible causes

- The indoor unit capacity has not been set by wired controller or remote controller.

6.20.5 Procedure



6.21 H4 Troubleshooting

6.21.1 Display output



6.21.2 Description

- Communication error between indoor unit and panel.


6.21.3 Impact on other units

- Refer to 5.2 “Impact on Other Units”.

6.21.4 Possible causes

- Communication wire between IDU main board and display board not connected properly.
- Panel is not compatible with the indoor unit.

6.21.5 Procedure



7 Appendix

7.1 Temperature Sensor Resistance Characteristics

Table 6.1: Indoor ambient temperature sensor, indoor heat exchanger mid-point temperature sensor and indoor heat exchanger outlet temperature sensor resistance characteristics

| Temperature (°C) | Resistance (kΩ) | Temperature (°C) | Resistance (kΩ) | Temperature (°C) | Resistance (kΩ) | Temperature (°C) | Resistance (kΩ) |
|------------------|-----------------|------------------|-----------------|------------------|-----------------|------------------|-----------------|
| -20 | 115.3 | 20 | 12.64 | 60 | 2.358 | 100 | 0.6297 |
| -19 | 108.1 | 21 | 12.06 | 61 | 2.272 | 101 | 0.6115 |
| -18 | 101.5 | 22 | 11.50 | 62 | 2.191 | 102 | 0.5939 |
| -17 | 96.34 | 23 | 10.97 | 63 | 2.112 | 103 | 0.5768 |
| -16 | 89.59 | 24 | 10.47 | 64 | 2.037 | 104 | 0.5604 |
| -15 | 84.22 | 25 | 10.00 | 65 | 1.965 | 105 | 0.5445 |
| -14 | 79.31 | 26 | 9.551 | 66 | 1.896 | 106 | 0.5291 |
| -13 | 74.54 | 27 | 9.124 | 67 | 1.830 | 107 | 0.5143 |
| -12 | 70.17 | 28 | 8.720 | 68 | 1.766 | 108 | 0.4999 |
| -11 | 66.09 | 29 | 8.336 | 69 | 1.705 | 109 | 0.4860 |
| -10 | 62.28 | 30 | 7.971 | 70 | 1.647 | 110 | 0.4726 |
| -9 | 58.71 | 31 | 7.624 | 71 | 1.591 | 111 | 0.4596 |
| -8 | 56.37 | 32 | 7.295 | 72 | 1.537 | 112 | 0.4470 |
| -7 | 52.24 | 33 | 6.981 | 73 | 1.485 | 113 | 0.4348 |
| -6 | 49.32 | 34 | 6.684 | 74 | 1.435 | 114 | 0.4230 |
| -5 | 46.57 | 35 | 6.400 | 75 | 1.387 | 115 | 0.4116 |
| -4 | 44.00 | 36 | 6.131 | 76 | 1.341 | 116 | 0.4006 |
| -3 | 41.59 | 37 | 5.874 | 77 | 1.291 | 117 | 0.3899 |
| -2 | 39.82 | 38 | 5.630 | 78 | 1.254 | 118 | 0.3796 |
| -1 | 37.20 | 39 | 5.397 | 79 | 1.2133 | 119 | 0.3695 |
| 0 | 35.20 | 40 | 5.175 | 80 | 1.174 | 120 | 0.3598 |
| 1 | 33.33 | 41 | 4.964 | 81 | 1.136 | 121 | 0.3504 |
| 2 | 31.56 | 42 | 4.763 | 82 | 1.100 | 122 | 0.3413 |
| 3 | 29.91 | 43 | 4.571 | 83 | 1.064 | 123 | 0.3325 |
| 4 | 28.35 | 44 | 4.387 | 84 | 1.031 | 124 | 0.3239 |
| 5 | 26.88 | 45 | 4.213 | 85 | 0.9982 | 125 | 0.3156 |
| 6 | 25.50 | 46 | 4.046 | 86 | 0.9668 | 126 | 0.3075 |
| 7 | 24.19 | 47 | 3.887 | 87 | 0.9366 | 127 | 0.2997 |
| 8 | 22.57 | 48 | 3.735 | 88 | 0.9075 | 128 | 0.2922 |
| 9 | 21.81 | 49 | 3.590 | 89 | 0.8795 | 129 | 0.2848 |
| 10 | 20.72 | 50 | 3.451 | 90 | 0.8525 | 130 | 0.2777 |
| 11 | 19.69 | 51 | 3.318 | 91 | 0.8264 | 131 | 0.2708 |
| 12 | 18.72 | 52 | 3.192 | 92 | 0.8013 | 132 | 0.2641 |
| 13 | 17.80 | 53 | 3.071 | 93 | 0.7771 | 133 | 0.2576 |
| 14 | 16.93 | 54 | 2.959 | 94 | 0.7537 | 134 | 0.2513 |
| 15 | 16.12 | 55 | 2.844 | 95 | 0.7312 | 135 | 0.2451 |
| 16 | 15.34 | 56 | 2.738 | 96 | 0.7094 | 136 | 0.2392 |
| 17 | 14.62 | 57 | 2.637 | 97 | 0.6884 | 137 | 0.2334 |
| 18 | 13.92 | 58 | 2.540 | 98 | 0.6682 | 138 | 0.2278 |
| 19 | 13.26 | 59 | 2.447 | 99 | 0.6486 | 139 | 0.2223 |



OMEGA
ENVIRONMENTAL
TECHNOLOGIES LLC.

17702 Mitchell North, #101
Irvine, CA. 92614 .USA
Tel: 714 795 2830
Fax: 714 966 1646
info@omegavrf.com
www.omegavrf.com

OTECTM
AIR CONDITIONING

Showroom & Technology Center
11380 Interchange Circle North
Miramar, FL 33025 .USA
Tel: 305 901 1270
Fax: 954 212 8280
info@otecomega.com
www.otecomega.com

BEWMQ3A-SM1D0123