


HWSS018
SUPER HYBRID INVERTER
High Wall Split Heat Pump
INSTALLATION MANUAL

ENGLISH

- ✓ Read this Manual before the operation and keep it for reference.
- ✓ Read all safety precautions on the manual, improper use can cause serious injury.

Specification and performance data listed herein are subject to change without notice

OTEC is a product of OMEGA Environmental Technologies LLC.



◆ CONTENTS

Operation and maintenance

- Notices for operation 1
- Notices for use 3
- Names and functions of each part 5
- Operation of wireless remote control 6
- Emergency operation 11
- Clean and care 12
- Troubleshooting 14
- Installation service
- Notices for installation 17
- Installation dimension diagram 19
- Install indoor unit 20
- Install outdoor unit 22
- Install PV-module 24
- Check after installation and test operation 30
- Installation and Maintenance of Healthy Filter 31

This symbol stands for the items should be forbidden. This symbol stands for the items should be followed

The products in this manual may be different with the real one, according to different models, some models have displayer and some models without displayer, the position and shape of the displayer please refer to the real one.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.









Do not dispose this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.

Note: All the pictures in this manual are just schematic diagrams. The actual product is the standard.

◆ Operation and maintenance-notice for operation

<p> ★ Earth: The ground be connected!</p> <p>If not, please ask the qualified personnel to install. Furthermore, don't connect each wire to the gas pipe, water pipe, drainage pipe or any other improper places.</p>	<p>★ Be sure to pull out the power plug when not using the air conditioner for a long time.</p> <p>Otherwise, the accumulated dust may cause fire or electric shock.</p>	<p>★ Select the most appropriate temperature.</p> <p>Keep room cooler than outside about 5 degree.</p> <p>It can preclude the electricity wasted.</p>
<p>★ Don't leave windows and doors open for a long time while operating the air conditioner.</p> <p>It can decrease the air conditioning capacity.</p>	<p>★ Don't block the air intake or outlet vents of both the outdoor and indoor units.</p> <p>It can decrease the air conditioning capacity or cause a malfunction.</p>	<p>★ Keep combustible spray away from the units more than 1m.</p> <p>It can cause a fire or explosion.</p>
<p>★ Please note whether the installed stand is firm enough or not.</p> <p>If it is damaged, it may lead to the fall of the unit and cause the injury.</p>	<p>★ Don't step on the top of the outdoor unit or place something on it.</p> <p>As falling off the outdoor unit can be dangerous.</p>	<p>★ Don't attempt to repair the air conditioner by yourself.</p> <p>The wrong repair will lead to an electric shock or fire, so you should contact the service center to repair.</p>

◆ Notices for operation

<p>★ If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.</p> 	<p>★ The airflow direction can be adjusted appropriately. At operating, adjust the vertical airflow direction by adjusting the louvers of upward/downward direction. And then, hold two ends of left and right louver to adjust the horizontal airflow.</p> 
<p>★ Don't insert your hands or stick into the air intake or outlet vents.</p>  <p>Otherwise it will cause accident.</p>	<p>★ Don't blow the wind to animals and plants directly. It can cause a bad influence to them.</p> 
<p>★ Don't apply the cold wind to the body for a long time.</p>  <p>It can cause the health problems.</p>	<p>★ Don't use the air conditioner for other purposes, such as drying clothes, preserving foods, etc.</p> 
<p>★ Splashing water on the air conditioner can cause an electric shock and malfunction.</p> 	<p>★ Don't place a space heater near the air conditioner.</p>  <p>Or CO toxicosis may occur for incomplete burning.</p>

- 2 -

◆ Notices for use

Working principle and special functions for cooling

Principle:
Air conditioner absorbs heat in the room and transmit to outdoor and discharged, so that indoor ambient temperature decreased, its cooling capacity will increase or decrease by outdoor ambient temperature.

Anti-freezing function:
If the unit is running in COOL mode and in low temperature, there will be frost formed on the heat exchanger, when indoor heat exchanger temperature decreased below 0°C, the indoor unit microcomputer will stop compressor running and protect the unit.

Working principle and special functions for heating

Principle:
* Air conditioner absorbs heat from outdoor and transmits to indoor, in this way to increase room temperature. This is the heat pump heating principle, its heating capacity will be reduced due to outdoor temperature decrease.
* If outdoor temperature becomes very low, please operate with other heating equipments.

The Surplus Heat Blowing function:
when unit stop running, after the heating temperature arrived, indoor unit runs at setting fan speed for 60s.

Anti-cool wind function:
In "Heat" mode, under the following three kinds of state, if indoor heat exchanger doesn't arrive at certain temp., indoor fan will not act, in order to prevent cool wind blowing(within 2 mins):
1. Heating starts. 2.After Auto Defrost finished. 3.Heating under the low temperature.

Introduction of DC solar power management

The out-door unit can handle DC solar power input besides AC power input. If the solar power device (poly-crystalline solar panel for instance) were connected to out-door unit, the unit would preferentially consume the solar power. And the AC power would be synchronously consumed as complement. The rated voltage of DC solar power should be less than 165V and the rated current should be less than 9A.

- 3 -

◆ Notices for use


※ Working temperature range		
	Indoor sideDB/WB(°C)	Outdoor sideDB/WB(°C)
Maximum cooling	32/23	43/26
Minimum cooling	21/15	21/-
Maximum heating	27/-	24/18
Minimum heating	20/-	-7/-8

The operating temperature range (outdoor temperature) for cooling unit is 21°C~43°C; for cooling and heating unit is -7°C~43°C.

- All the electrical work must be done by qualified personnel according to relative wiring regulation and this manual.
- The power supply is type Y connection.If the supply cord is damaged,it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- The rated voltage and the exclusive circuit must be used.
- Leakage circuit-breaker and air switch of correct capacity must be installed,the air switch of 32A should be used in these models.
- The plug must be accessible after the appliances have been positioned.
- A air switch having a contact separation of at least 3mm in all poles should be fixed in fixed wiring.

- 4 -

◆ Names and functions of each part



Indoor unit

Outdoor unit

The pattern in displayer:

- ❄: Cool
- ☀: Dry
- 🌀: Fan
- 🔥: Heat
- ⏻: Run
- BB: Set temp.


(1) Power cable
(2) Remote control
(3) Front panel
(4) Filter
(5) Guide louver
(6) Wall pipe
(7) Bind tape
(8) Connection wire
(9) Drainage pipe

- 5 -

◆ Operation of wireless remote control

Names and functions of wireless remote control

Note: Be sure that there are no obstructions between receiver and remote controller; Don't drop or throw the remote control; Don't let any liquid in the remote control and put the remote control directly under the sunlight or any place where is very hot.



Signal transmitter

Remote control

SLEEP **SLEEP button**

- Press this button, Sleep On and Sleep Off can be selected. After powered on, Sleep Off is defaulted. After the unit is turned off, the Sleep function is canceled. After Sleep function set up, the signal of Sleep will display. In this mode, the time of timer can be adjusted. Under Fan and Auto modes, this function is not available.

FAN **FAN button**

- Press this button, Auto, Low, Middle, High speed can be circularly selected. After powered on, Auto fan speed is default.

Low fan Middle fan
High fan

Note: Under the Dry mode, the fan speed isn't adjustable, low fan speed is imperative, but when operating this button, the wireless adjustable, low fan speed is imperative.

CLOCK **CLOCK button**

- Press this button, the clock can be set up, signal blink and display. Within 5 seconds, the value can be adjusted by pressing + or - button, if continuously press this button for 2 seconds above, in every 0.5 seconds, the value on ten place of Minute will be increased 1. During blinking, the setting succeeded. After powered on, 12:00 is defaulted to display and signal will be displayed. If there is signal be displayed that denotes the current time value is Clock value, otherwise is Timer value.

LIGHT **LIGHT button**

- Press this button to select LIGHT on or off in the display. When the LIGHT on is set, the icon will be displayed and the indicator light in the display will be on. When the LIGHT off is set, the icon will be displayed and the indicator light in the display will be off.

ON/OFF **ON/OFF button**

- Press this button, the unit will be turned on, press it once more, the unit will be turned off. When turning on or turning off the unit, the Timer, Sleep function will be canceled, but the presetting time is still remained.

MODE **MODE button**


- Press this button, Auto, Cool, Dry, Fan, Heat mode can be selected circularly. Auto mode is default while power on. Under Auto mode, the temperature will not be displayed; Under Heat mode, the initial value is 28°C (82°F). Under other modes, the initial value is 25°C (77°F).

only for cooling and heating unit

◆ Operation of wireless remote control

Names and functions of wireless remote control

Notice: This is a general use remote controller, it could be used for the air conditioners with multifunction; For some function, which the model doesn't have, if press the corresponding button on the remote controller that the unit will keep the original running status.



Remote control

X-FAN **X-FAN button**

- Press this button, can turn on or turn off the drying. In Cool and Dehumidifying mode, press this button and will display " ", at this time the X-FAN is turned on. If repress this button, " " will be concealed, at this time the X-FAN function is turned off. After powered on, X-FAN OFF is defaulted. When operating the ON/OFF button, or switching mode to Cool or Dehumidifying mode, the X-FAN function will keep the original status. If unit is turned off, X-FAN OFF only can be set up and send the signal. In Auto, Fan as well as Heat mode, X-FAN function can not be set up and there is no " " displaying. **Note:** X-FAN is the alternative expression of BLOW for the purpose of understanding.

+ button

- For presetting temperature increasing. Press this button, can set up the temperature, when unit is on. Continuously press and hold this button for more than 2 seconds, the corresponding contents will be changed rapidly, until unpress the button then send the information, °C (°F) is displaying all along. In Auto mode, the temperature can not be set up, but operate this button can send the signal. Centigrade setting range :16-30; Fahrenheit scale setting range 61-86.

TURBO **TURBO button**

- In Cool or Heat mode, press this button can turn on or turn off the Turbo function. After turned on the Turbo function, its signal will be displayed. When switching the mode or changing fan speed, this function will be canceled automatically.

TEMP **TEMP button**

- Press this button, could select displaying the indoor setting temperature or indoor ambient temperature. When the indoor unit firstly power on it will display the setting temperature, if the temperature's displaying status is changed from other status to " ", displays the ambient temperature, 5s later or within 5s, it receives other remote control signal that will return to display the setting temperature. If the users haven't set up the temperature displaying status, that will display the setting temperature. (This function is applicable to partial of models)


- button

- Presetting temperature can be decreased. Press this button, the temperature can be set up, continuously press this button and hold for two seconds, the relative contents can quickly change, until unhold this button and send the order that the °C (°F) signal will be displayed all the time. The temperature adjustment is unavailable under the Auto mode, but the order can be sent by if pressing this button.

◆ Operation of wireless remote control

Names and functions of wireless remote control

Notice: This is a general use remote controller, it could be used for the air conditioners with multifunction; For some function, which the model doesn't have, if press the corresponding button on the remote controller that the unit will keep the original running status.



Remote control

SWING UP AND DOWN BUTTON

- Press this button, to set up swing angle, which circularly changes as below:

This is an universal use remote controller. If remote controller sends the following three kinds of status that the swing status of main unit will be:

When the guide louver start to swing up and down, if turn off the Swing, the air guide louver will stop at current position.

which indicates the guide louver swings up and down between that all five positions.

TIMER ON **TIMER ON BUTTON**

- Timer On setting: Signal "ON" will blink and display. When the LIGHT on is set, the numerical section will become the timer on setting status. During 5 seconds blink, by pressing + or - button to adjust the time value of numerical section, every press of that button, the value will be increased or decreased 1 minute. Hold pressing + or - button, 2 seconds later, it quickly change, the way of change is: During the initial 2.5 seconds, ten numbers change in the one place of minute, then the one place is constant, ten numbers change in the tens place of minute at 2.5 seconds speed and carry. During 5s blink, press the Timer button, the timer setting succeeds. The Timer On has been set up, repress the timer On button, the Timer On will be canceled. Before setting the Timer, please adjust the Clock to the current actual time.


TIMER OFF **TIMER OFF BUTTON**

- Once press this key to enter into TIMER OFF setup, in which case the TIMER OFF icon will blink. The method of setting is the same as for TIMER ON.

◆ Operation of wireless remote control


Guide for operation- General operation

- After powered on, press ON/OFF button, the unit will start to run. (Note: When it is powered on, the guide louver of main unit will close automatically.)
- Press MODE button, select desired running mode.
- Pressing + or - button, to set the desired temperature. (It is unnecessary to set the temp. at AUTO mode.)
- Pressing FAN button, set fan speed, can select AUTO FAN, LOW, MID and HIGH.
- Pressing button, to select the swing.



Guide for operation- Optional operation

- Press SLEEP button, to set sleep.
- Press TIMER ON and TIMER OFF button, can set the scheduled timer on or timer off.
- Press LIGHT button, to control the on and off of the displaying part of the unit (This function may be not available for some units).
- Press TURBO button, can realize the ON and OFF of TURBO function.



Introduction for special function

★ About X-FAN function

This function indicates that moisture on evaporator of indoor unit will be blown after the unit is stopped to avoid mould.

- Having set X-FAN function on: After turning off the unit by pressing ON/OFF button indoor fan will continue running for about 10 min. at low speed. In this period, press X-FAN button to stop indoor fan directly.
- Having set X-FAN function off: After turning off the unit by pressing ON/OFF button, the complete unit will be off directly.

★ About AUTO RUN


When AUTO RUN mode is selected, the setting temperature will not be displayed on the LCD, the unit will be in accordance with the room temp. automatically to select the suitable running method and to make ambient comfortable.

★ About turbo function



If start this function, the unit will run at super-high fan speed to cool or heat quickly so that the ambient temp. approaches the preset temp. as soon as possible.

◆ Operation of wireless remote control

★ About lock

Press + and - buttons simultaneously to lock or unlock the keyboard. If the remote controller is locked, the icon  will be displayed on it, in which case, press any button, the mark will flicker for three times. If the keyboard is unlocked, the mark will disappear.


★ About swing up and down


1. Press swing up and down button continuously more than 2s, the main unit will swing back and forth from up to down, and then loosen the button, the unit will stop swinging and present position of guide louver will be kept immediately.
2. Under swing up and down mode, when the status is switched from off to , if press this button again 2s later,  status will switch to off status directly; if press this button again within 2s, the change of swing status will also depend on the circulation sequence stated above.

★ About switch between Fahrenheit and Centigrade

Under status of unit off, press MODE and - buttons simultaneously to switch °C and °F.

Changing batteries and notices

1. Slightly to press the place with , along the arrowhead direction to push the back cover of wireless remote control. (As show in figure)
2. Take out the old batteries. (As show in figure)
3. Insert two new AAA1.5V dry batteries, and pay attention to the polarity. (As show in figure)
4. Attach the back cover of wireless remote control. (As show in figure)





★ NOTE:

- When changing the batteries, do not use the old or different batteries, otherwise, it can cause the malfunction of the wireless remote control.
- If the wireless remote control will not be used for a long time, please take them out, and don't let the leakage liquid damage the wireless remote control.
- The operation should be in its receiving range.
- It should be placed at where is 1m away from the TV set or stereo sound sets.
- If the wireless remote control can not operate normally, please take them out, after 30s later and reinsert, if they cannot normally run, please change them.

◆ Emergency operation

Displayer indicator light control of indoor unit

It's a special selective button for the users ,who are not accustomed to the light at sleeping.

- Get the displayer indicator light on: When setting the light function, the mark  will display on the remote controller screen by pressing this button. In which case, the displayer indicator light will be on if the AC receives this signal.
- Get the displayer indicator light off: If cancel the light function, the mark  will disappear on the remote controller screen by pressing this button. In which case, the displayer indicator light will be off if the AC receives this signal.

Emergency operation

If the wireless remote control is lost or broken, please use the manual switch button. At this time, the unit will run at the Auto mode, but the temperature and fan speed cannot be changed. The operation was shown as below:




Fig.3

To open the panel, the manual switch is on the displayer box.

- Turn on the unit: At unit turned off, press the button, the unit will run at Auto mode immediately. The microcomputer will accord to the indoor temperature to select (Cooling, Heating, Fan) and obtain the comfortable effect.
- Turn off the unit: At unit turned on, press the button, the unit will stop working.

◆ Clean and care



Caution

- Turn power off and pull out the power plug before cleaning air conditioner, or it may cause electric shock.
- Never sprinkle water on the indoor unit and the outdoor unit for cleaning because it can cause an electric shock.
- Volatile liquid (e.g. thinner or gasoline) will damage the air conditioner. (So wipe the units with a dry soft cloth, or a cloth slightly moistened with water or cleanser.)

Clean the front panel

When cleaning the front panel, please dip the cloth into the water temperature of 45°C below, then to dry the cloth and wipe the dirty part.



Note: Please do not to immerse the front panel in water, due to there are microcomputer components and circuit diagrams on the front panel.

Clean the air filter (Recommended once every three months)

NOTE: If dust is much more around the air conditioner, the air filters should be cleaned many times. After taking off the filter, don't touch the fin of indoor unit, in order to avoid hurt your fingers.

① Take down the air filter

At the slot of surface panel to open an angle, pull the air filter downward and take it out, please see the Fig. 4(a, b).



② Clean the air filter

To clean the dust adhering to the filters, you can either use a vacuum cleaner, or wash them with warm water the water with the neutral detergent should below 45 degree), and dry it in the shade.

NOTE: Never use water above 45°C to clean, or it can cause deformation or discoloration. Never parch it by fire, or can cause a fire or deformation.



③ Insert the air filter


Reinsert the filters along the direction of arrowhead, and then to cover the cover and clasp it.



◆ Clean and care

Check before use












- ① Be sure that nothing obstructs the air outlet and intake vents.
- ② Check that whether ground wire is properly connected or not.
- ③ Check that whether the batteries of air conditioner are changed or not.
- ④ Check that whether the installation stand of the outdoor unit is damaged or not. If damaged, please contact the dealer.



Maintain after use








- ① Turn main power off.
- ② Clean the filter and indoor and outdoor units' bodies.
- ③ Clear dust and obstructions from the outdoor unit.
- ④ Repaint the rubiginous place on the outdoor unit to prevent it from spreading.
- ⑤ Adopt the special shield to cover the outdoor unit, avoid the rain water, dust enter into the unit and get rust.

◆ Troubleshooting

 CAUTION Don't attempt to repair the air conditioner by yourself, it can cause an electric shock or fire. Please check the following items before asking for repair, it can save your time and money.	
Phenomenon	Troubleshooting
Not operate immediately when the air conditioner is restarted.  	<ul style="list-style-type: none"> Once the air conditioner is stopped, it will not operate in approximately 3 minutes to protect itself.
There's unusual smell blowing from the outlet after operation is started.  	<ul style="list-style-type: none"> The unit has no peculiar smell by itself. If has that is due to the smell accumulated in the ambient. Solution method: Cleaning the filter. If problem still has, so need to clean air conditioner. (Please contact with the authorized maintenance center.)
Sound of water flow can be heard during the operation.  	<ul style="list-style-type: none"> The air conditioner is started, when it is running the compressor started or stopped running, or the unit is stopped, sometimes there is swoosh or gurgle, the sound is due to refrigerant flowing they are not malfunctions.
In COOL mode, sometimes the mist emitted from the air outlet vent.  	<ul style="list-style-type: none"> When the indoor temperature and humidity are very high, this phenomenon would happen. This is caused by the room air is swiftly cooled down. After running for a while, indoor temperature and humidity will fall down, the mist will die away.
Creaking noise can be heard when start or stop the unit.  	<ul style="list-style-type: none"> This is caused by the deformation of plastic due to the changes of temperature.


- 14 -

◆ Troubleshooting

Phenomenon	Troubleshooting
The unit can not run.   	<ul style="list-style-type: none"> Has the power been shut down? Is power plug loosed? Is the circuit protection device tripped off or not? Is voltage higher or lower? (Tested by professionals) Is the TIMER correctly used?
Cooling(Heating) efficiency is not good.  	<ul style="list-style-type: none"> Is Temp. setting suitable? Were inlet and outlet vents obstructed? Is filter dirty? Are the windows and doors closed? Did Fan speed set at low speed? Is there any heat sources in the room?
Wireless remote control is not available.  	<ul style="list-style-type: none"> The unit is interfered by abnormal or frequent functions switchover occasionally the controller cannot operate. At this time, you need to pull out of the plug, and reinsert it. Is it in its receiving range? Or obstructed? To check the voltage in wireless remote control inside is charged, otherwise to replace the batteries. Whether the wireless remote control is damaged.
If water leakage in the room.	<ul style="list-style-type: none"> The air humidity is on the high side. Condensing water over flowed. The connection position of indoor unit drainage pipe is loosed.
If water leakage in outdoor unit.	<ul style="list-style-type: none"> When the unit is running in COOL mode, the pipe and connection of pipe would be condensed due to the water cooled down. When the unit is running in Auto Defrosting mode the ice thawed and flowed out. When the unit is running in HEAT mode, the water adhered on heat exchanger dripped off.
Noise from indoor unit emitted.	<ul style="list-style-type: none"> The sound of fan or compressor relay is switching on or off. When the defrosting is started or stop running, it will sound. That is due to the refrigerant flowed to the reverse direction.


- 15 -

◆ Troubleshooting

Phenomenon	Troubleshooting
Indoor unit cannot deliver air.	<ul style="list-style-type: none"> In HEAT mode, when the temperature of indoor heat exchanger is very low, that will stop deliver air in order to prevent cool air. (Within 2min) In HEAT mode, when the outdoor temperature is low or high humidity, there are much frost be formed on the outdoor heat exchanger, that the unit will automatically defrost, indoor unit stop blowing air for 3-12min. During the defrosting, there is water flowing out or vapor be produced. In dehumidifying mode, sometimes indoor fan will stop, in order to avoid condensing water be vaporized again, restrain temperature rising.
Moisture on air outlet vent.	<ul style="list-style-type: none"> If unit is running under the high humidity for a long time, the moisture will be condensed on the air outlet grill and drip off.
 Immediately stop all operations and plug out, contact the dealer in following situations.	
<div style="border: 1px solid black; padding: 5px;"> <p>There is harsh sound during operation. The terrible odors emitted during operation. Water is leaking in the room. Air switch or protection switch often breaks. Carelessly splash water or something into unit. There is an abnormal heat in power supply cord and power plug.</p> </div> <div style="border: 1px solid black; border-radius: 15px; padding: 5px; display: inline-block; margin-left: 20px;"> Stop running and pull out of the plug. </div>	

- 16 -

◆ Notices for installation

 Important Notices
<ol style="list-style-type: none"> The unit installation work must be done by qualified personnel according to the local rules and this manual. Before installing, please contact with local authorized maintenance center, if unit is not installed by the authorized maintenance center, the malfunction may not solved, due to discommodious contacts. When removing the unit to the other place, please firstly contact with the authorized Maintenance Center in the local area.
Basic Requirements For Installation Position
Install in the following place may cause malfunction. If it is unavoidable contact with service center please: <ul style="list-style-type: none"> Place where strong heat sources, vapors, flammable gas or volatile object are emitted. Place where high-frequency waves are generated by radio equipment, welders and medical equipment. Place where a lot of salinities such as coast exists. Place where the oil (machine oil) is contained in the air. Place where a sulfured gas such as the hot spring zones is generated. Other place with special circumstance.
Indoor Unit Installation Position Selection
<ol style="list-style-type: none"> The air inlet and outlet vent should be far from the obstruction, make sure that the air can be blown through the whole room. Select a position where the condensing water can be easily drained out, and the place is easily connected for outdoor unit. Select a location where the children can not reach. Can select the place where is strong enough to withstand the full weight and vibration of the unit. And will not increase the noise. Be sure to leave enough space to allow access for routine maintenance. The height of the installed location should be 250cm or more from the floor. Select a place about 1m or more away from TVset or any other electric appliances. Select a place where the filter can be easily taken out. Make sure that the indoor unit installation should accord with installation dimension diagram requirements. Do not use the unit in the immediate surroundings of a laundry a bath a shower or a swimming pool.
Outdoor Unit Installation Position Selection
<ol style="list-style-type: none"> Select a location from which noise and outflow air emitted by unit will not inconvenience neighbors, animals, plants. Select a location where there should be sufficient ventilation. Select a location where there should be no obstructions cover the inlet and outlet vent. The location should be able to withstand the full weight and vibration of the outdoor unit and permit safe installation. Select a dry place, but do not expose under the direct sunlight or strong wind. Make sure that the outdoor unit installation dimension should accord with installation dimension diagram, convenient for maintenance, repair. The height difference of connecting the tubing within 5m, the length of connecting the tubing within 10m. Select a place where it is out of reach for the children. Select a place where will not block the passage and do not influence the city appearance.

- 17 -

◆ Notices for installation

Safety Requirements For Electric Appliances

1. The power supply should be used the rated voltage and AC exclusive circuit, the power cable diameter should be satisfied.
2. Don't drag the power cable emphatically.
3. It should be reliably earthed, and it should be connected to the special earth device, the installation work should be operated by the professional.
The air switch must have the functions of magnetic tripping and heat tripping, in order to protect the short circuit and overloading.
4. The min. distance from the unit and combustive surface is 1.5m.
5. The appliance shall be installed in accordance with national wiring regulations.
6. An all-pole disconnection switch having a contact separation of at least 3mm in all poles should be connected in fixed wiring.
7. Poly-crystalline solar panel is strongly recommended as solar power device. The rated voltage of DC solar power should be less than 165V and the rated current should be less than 10A. Take the poly-crystalline solar panel of 200W (open-circuit voltage:33V, short-circuit current:8.12A)for instance, the maximum number in one series of of panels is 5, and the connention method should be series connection.

Note:

- ⚠ Make sure that the Live wire or Zero line as well as the earth wire in the family power socket can not be wrong connected, there should be reliable and no short circuit in the diagram.
- ⚠ wrong connection may cause fire.


Earthing requirements

1. Air conditioner is type I electric appliance, thus please do conduct reliable earthing measure.
2. The yellow-green two-color wire in air conditioner is earthing wire and cannot be used for other propose. It cannot be cut off and be fix it by screw, otherwise it would cause electric shock.
3. The earth resistance should accord to the National Criterion.
4. The user power must offer the reliable earthing terminal. Please don't connect the earthing wire with the following place:
 - ① Tap water pipe.
 - ② Gas pipe.
 - ③ Contamination pipe.
 - ④ Other places that professional personnel consider them unreliable.
5. The model and rating values for fuses according the silk print on fuse cover or related PCB board.

- 18 -

◆ Installation dimension diagram

Installation dimension diagram




- 19 -

◆ Install indoor unit


Install the rear panel

1. Always mount the rear panel horizontally. Due to the water tray of indoor unit has been adopted the both-way drainage design, the outlet of water tray should be adjusted slightly down when installing, that is taking the outlet of the water tray as the center of a circle, the included angle between the evaporator and level should be 0 or more, that is good for condensing water drainage.
2. Fix the rear panel on the wall with screws. (Where is pre-covered with plastic granula)
3. Be sure that the rear panel has been fixed firmly enough to withstand the weight of an adult of 60kg, further more, the weight should be evenly shared by each screw.




Install the piping hole

1. Make the piping hole (Φ55) in the wall at a slight downward slant to the outdoor side.
2. Insert the piping-hole sleeve into the hole to prevent the connection piping and wiring from being damaged when passing through the hole.




Install the water drainage pipe

1. For well draining, the drain hose should be placed at a downward slant.
2. Do not wrench or bend the drain hose or flood its end by water.
3. When the long drainage hose passing through indoor, should wrap the insulation materials.



Connect indoor and outdoor electric wires

1. Open the surface panel.
2. Remove the wiring cover Fig.6.
3. Route the power connection cord and signal control wire (for cooling and heating unit only) from the back of the indoor unit and pull it toward the front through the wiring hole for connection.
4. Connect the interconnection cord to the terminal block, and then fix the cord with cord anchorage.
5. Reassemble the clamp and wiring cover.
6. Recover the surface panel.



- 20 -

◆ Install indoor unit

NOTE:


When connecting the electric wire if the wire length is not enough, please contact with the authorized service shop to buy a exclusive electric wire that is long enough and the joint on the wire are not allowed.

- The electric wiring must be correctly connected, wrong connection may cause spare parts malfunction.
- Tighten the terminal screw in order to prevent loose.
- After tighten the screw, slight pull the wire and confirm whether is it firm or not.
- If the earth wire is wrong connection, that may cause electric shock.
- The cover plate must be fixed, and tighten the connection wire, if it is poor installed, that the dust, moisture may enter in or the connection terminal will be affected by outside force, and will cause fire or electric shock.


Install the indoor unit

- The piping can be lead out from right, right rear, left left rear.

1. When routing the piping and wiring from the left or right side of indoor unit, cut off the tailings from the chassis in necessary (Show in Fig.7)
 - (1) Cut off the tailings 1 when routing the wiring only;
 - (2) Cut off the tailings 1 and tailings 2 when routing both the wiring and piping.




2. Take out the piping from body case, wrap the piping electric wire, water pipe with tape and pull them through the piping hole (As show in Fig.8)
3. Hang the mounting slots of the indoor unit on the upper tabs of the rear panel and check if it is firm enough. (As show in Fig.9)
4. The height of the installed location should be 2.5m or more from the floor.



Install the connection pipe

1. Align the center of the piping flare with the relevant valve.
2. Screw in the flare nut by hand and then tighten the nut with spanner and torque wrench refer to the following:

Hex nut diameter	Tightening torque (N · m)
Φ6	15~20
Φ9.52	31~35
Φ12	50~55
Φ16	60~65
Φ19	70~75




NOTE: Firstly connect the connection pipe to indoor unit, then to outdoor unit; pay attention to the piping bending, do not damage the connection pipe; the joint nut couldn't tighten too much, otherwise it may cause leakage.

- 21 -

◆ Install outdoor unit

Electric wiring

1. Disassemble the handle on the outdoor unit right side plate.
2. Take off cord anchorage. Connect and fix power connect cord (for cooling and heating unit, connect and fix power connect cord and signal control wire) to terminal block.
3. Fix the power connection cable with cord anchorage, (for cooling and heating unit, use the cord anchorage to fix the power connection cable and the signal control wire).
4. Ensure wire has been fixed well.
5. Install the handle.



NOTE:

- Wrong wiring may cause spare parts malfunction.
- After the cable fixed, make sure there should be a free space between the connection and connection and fixing place on the lead wire.
- The rated voltage of solar power should be less than 165V and the rated current of solar power should be less than 9A.

◆ Install outdoor unit

Air purging and leakage test

1. Connect charging hose of manifold valve to charge end of low pressure valve (both high/low pressure valves must be tightly shut).
2. Connect joint of charging hose to vacuum pump.
3. Fully open handle of Lo manifold valve.
4. Open the vacuum pump to evacuate. At the beginning, slightly loosen joint nut of low pressure valve to check if there is air coming inside. (If noise of vacuum pump has been changed, the reading of multimeter is 0) Then tighten the nut.
5. Keep evacuating for more than 15mins and make sure the reading of multi-meter is -1.0×10^5 pa (-76cmHg).
6. Fully open high/low pressure valves.
7. Remove charging hose from charging end of low pressure valve.
8. Tighten bonnet of low-pressure valve. (As shown in Fig.10)





Fig.10

Condensate drainage of outdoor unit (no for cooling only)

The condensate and defrosting water formed during heating in the outdoor unit can be properly discharged by drainage pipe.

Installation method: set the drain connection in $\varnothing 25$ hole of the chassis has been installed and then connect drainage pipe with drain nozzle, so that condensate and defrosting water can be properly discharged.



◆ Install PV-Module

PV-Module Characteristics

Electrical Characteristics


Open - Circuit Voltage (Voc)	33.4V
Optimum Operating Voltage (Vmp)	26.2V
Short - Circuit Current (Isc)	8.12A
Optimum Operating Current (Imp)	7.63A
Maximum Power at STC (Pmax)	200Wp
Operating Temperature	-40°C to +85°C
Maximum System Voltage	600V DC
Maximum Series Fuse Rating	20AMPS
Power Tolerance	±3 %

Mechanical Characteristics

Solar Cell	Poly-crystalline 156×156mm (6inch)
No. of Cells	54 (6×9)
Dimensions	1482×992×35mm (58.3×39.1×1.4inch)
Weight	16.8kg (37.0lbs.)
Front Glass	3.2 mm (0.13inch) tempered glass
Frame	Anodized aluminium alloy
Junction Box	IP65 rated
Output Cables	LAPP (4.0mm ²), asymmetrical lengths (-) 1200mm(47.2inch) and (+) 800mm (31.5inch), MC Plug Type IV connectors

STC: Irradiance 1000W/m², Module temperature 25°C, AM=1.5

Current-Voltage & Power-Voltage Curve




◆ Install PV-Module

Mechanical Installation

1. Mechanical Installation of PV-modules should be operated by professional solar photovoltaic installation guides or reputable solar installer or systems integrator.
2. Omega do not provide any mechanical installation guide of PV-modules, as a result, Omega will not provide any instructor or after service for the problems of mechanical installation of PV-modules.

Electrical Installation


1. General Installation
 - Any hardware used must be compatible with the mounting structure material to avoid galvanic corrosion
 - It is not recommended to use modules with different configurations in the same system.
 - Several modules should be connected in series to form a string of modules if needed. The maximum number of series connected modules is 5.
 - MC-4 connector is the recommended connector and the recommended system wires size is AWG12.
2. Installation Sketch



◆ Install PV-Module


Assembly of PV-wire

1. The PV-wire should be single-pole, double insulated solar cable, the length of which is due to the distance from PV-modules to outdoor unit of AC, the recommended conductor cross section is AWG12, and it should accord with UL4703.
2. The MC-4 Connectors should be assembled to the PV-wires, and the other side of the PV-wires should be assembled with spade terminals.



Assembly of MC-4 Connector

1. Introduction of MC-4 Connector
The MC-4 Connector contains three Parts, male PV cable coupler (PV-KST4/6II-UR), female PV cable coupler (PV-KBT4/6II-UR) and a safety lock clip (PV-SSH4).



2. Assembly Method

◆ Install PV-Module

	Introduction	Photo	Recommended tool
Step1	Strip cable insulation. L = 6-7.5 mm. Take care not to cut individual strands.		Stripping pliers: PV-AZM-1.5/6 Interchangeable blade: PV-M-AZM-156
Step2	Open and hold clamping clip (K). Insert contact in the appropriate cross-section range of the crimping tool. Turn contact till crimping tabs face the top. Release clamping clip (K). The contact is secured.		Crimping pliers: PV-CZM-19100 Insert: PV-ES-CZM-19100 Locator: PV-LOC
Step3	Lightly press the pliers together so that the crimping tabs lie securely within the crimping die.		

◆ Install PV-Module

Step4	Insert the stripped cable until the insulation comes into contact with the crimping insert. Close crimping tool completely. Check crimp.		
Step5	Push the crimped contact into the socket resp. plug insulator until it engages. Pull lightly on the lead to check that the metal part has engaged.		
Step6	Insert the test pin with the corresponding side into the socket or plug to the end position. If the contact is correctly assembled, the white marking on the test pin must be still visible.		Test plug PV-PST
Step7	Screw on the cable gland, hand-tight, with the tools PV-MS. The tightening torque must be adapted to the solar cables used in each specific case. Typical values lie in a range between 2,5Nm to 3Nm.		Open-end spanner PV-MS 1 set = 2 pieces

◆ Install PV-Module

Step8	Plug the coupling together until they engage. Check correct engagement by pulling on the coupling.		
Step9	Compress the two snapin springs (X) by hand or with the PV-MS tool and separate the coupling.		
Step10	Plugging: Mount the plug connection until it engages. Check correct engagement by pulling on the coupling. Unplugging: The plug connection can only be unlocked with the tool PV-MS.		PV-SSH4

◆ Check after installation and test operation

Check after installation

Items to be checked	Possible malfunction
Has it been fixed firmly?	The unit may drop, shake or emit noise.
Have you done the refrigerant leakage test?	It may cause insufficient cooling(heating) capacity.
Is heat insulation sufficient?	It may cause condensation and dripping.
Is water drainage well?	It may cause condensation and dripping.
Is the voltage in accordance with the rated voltage marked on the nameplate?	It may cause electric malfunction or damage the part.
Is the electric wiring and piping connection installed correctly and securely?	It may cause electric malfunction or damage the part.
Has the unit been connected to a secure earth connection?	It may cause electrical leakage.
Is the power cord specified?	It may cause electric malfunction or damage the part.
Is the inlet and outlet been covered?	It may cause insufficient cooling(heating) capacity.
Has the length of connection pipes and refrigerant capacity been recorded?	The refrigerant capacity is not accurate.
Is the PV-wire installed correctly and securely?	It may cause PV-modules not work or damage the PV-modules.
Is the MC-4 connectors plugged correctly and securely?	It may cause PV-modules not work.
Test the voltage of L+ and L- to ensure the PV-modules is connected to AC correctly.	It may cause PV-modules not work.


Test Operation

- Before test operation
 - Do not switch on power before installation is finished completely.
 - Electric wiring must be connected correctly and securely.
 - Cut-off valves of the connection pipes should be opened.
 - All the impurities such as scraps and thrums must be cleared from the unit.
- Test operation method
 - Switch on power, press "ON/OFF" button on the wireless remote control to start the operation.
 - Press MODE button, to select the COOL, HEAT (Cooling only unit is not available), FAN to check whether the operation is normal or not.

◆ Installation and Maintenance of Healthy Filter

Installation Instructions

- Forcibly pull the panel for a specific angle from the two ends of the front panel according to the arrow direction. Then pull the air filter downwards to remove it. (See Fig.a)
- Mount the healthy filter onto the air filter, (as shown in Fig.b). If the air filter cannot be installed, please mount the healthy filter on the front case. (as shown in Fig.c)
- Mount the air filter properly along the arrow direction in Fig.d, and then close the panel cover.



Cleaning and Maintenance

Take out the healthy filter before cleaning and reinstall it after cleaning according to the installation instruction. Pay special attention to that silver ion filter can't be cleaned with water, while active carbon, photocatalyst, low temperature conversion (LTC) catalyst, formaldehyde eliminator, catechin or mite killing filter can, but can't with brush or hard things. Dry it in the shade or sun after cleaning, but not by wiping.

Service Life

The healthy filter commonly has its usage lifetime for one year under normal condition. As for silver ion filter, it is invalid when its surface becomes black (green).

● This supplementary instruction is provided for reference to the unit with healthy filter. If the graphics provided herein is different from the physical goods, the latter one shall prevail. The quantity of healthy filters shall be based on the actual delivery.



OMEGA Super Hybrid High Wall Split Heat Pump



17702 Mitchell North, #101
Irvine, CA, 92614, USA
Tel: 714 795 2830
Fax: 714 966 1646
info@omegainverter.com
www.omegainverter.com



Showroom & Technology Center
11380 Interchange Circle North
Miramar, FL 33025, USA
Tel: 305 901 1270
Fax: 954 212 8280
info@otecus.com
www.otecus.com